



INSPECT, CLOSE & PLACE

STEPS 01-04

PT-203BK coated galvanized multi-catch mice trap - solid black lid / read all steps before use

LIVE-CAPTURE DEVICE - CHECK FREQUENTLY / KEEP BOTH SHORT-END ENTRANCES CLEAR

01 OPEN & INSPECT



ACTION

Wear gloves. On a dry, level surface, release the lid tabs and lift the single solid black top on its long-edge hinge. Confirm the coated case and chamber are clean and undamaged.

KEY CHECK

One solid hinged lid; chamber empty

02 VERIFY TWO TUNNELS



ACTION

Confirm exactly two enclosed galvanized tunnel modules are fitted. Each one-way flap and entry path must move freely, return normally and contain no debris or loose parts.

KEY CHECK

Two modules fitted; paths clear

03 CLOSE & SECURE



ACTION

Lower the solid top without touching either tunnel module. Engage the lid tabs so the black lid sits flush all around, with no gap or distortion at the hinge or edges.

KEY CHECK

Solid lid secured and flush

04 PLACE ALONG A WALL



ACTION

Set the closed trap flat on a dry floor with its long rear edge parallel and close to a wall runway. Keep both short-end entrance openings fully unobstructed.

KEY CHECK

Two end entries follow the wall run



PRODUCT REFERENCE / PT-203BK

Galvanized steel / black powder-coated exterior / 26 x 16 x 5 cm / 620 g

No clear window. Secure the solid lid and keep both short-end entrances unobstructed.



CHECK, RELEASE & SERVICE

STEPS 05-08

PT-203BK coated galvanized multi-catch mice trap - solid black lid / read all steps before use

LIVE-CAPTURE DEVICE - CHECK FREQUENTLY / KEEP BOTH SHORT-END ENTRANCES CLEAR

05 OPEN TO INSPECT



ACTION

At least daily, set the unit on a dry, level surface. Keep it flat and controlled while lifting the solid top to check the chamber. If occupied, close and secure the lid fully before moving.

KEY CHECK

Open level; reclose before moving

06 MOVE THE CLOSED TRAP



ACTION

Wear gloves. Keep the lid closed and carry the trap level with both hands supporting the solid base. Move only to a release location permitted by local requirements.

KEY CHECK

Closed, level and supported below

07 RELEASE VIA OPEN TOP



ACTION

At a permitted release site, set the trap on the ground facing away from people. Open the full solid top, withdraw both hands and allow the mouse to leave without touching or shaking it.

KEY CHECK

Open top is the release route

08 DISINFECT, WIPE & DRY



ACTION

Wear gloves. Apply labelled disinfectant until contaminated surfaces are wet and observe its contact time. Wipe the empty chamber, dry fully and recheck both tunnels before reuse.

KEY CHECK

No dry sweeping; two tunnels rechecked

SAFETY & SERVICE

Designed for mice. Keep the trap out of reach of children, pets and non-target animals. Wear rubber or plastic gloves when handling a capture or contaminated trap. Do not sweep or vacuum dry rodent waste; wet it with a labelled disinfectant and observe the contact time. Follow local animal-welfare, transport and release requirements. Clean gloved hands before removing gloves, then wash hands with soap and warm water.