



OPEN, CHECK & PLACE

STEPS 01-04

PT-203WH steel multi-catch mouse trap / solid lid / read all steps before use

LIVE-CAPTURE DEVICE - OPEN SOLID LID TO INSPECT / KEEP BOTH END ENTRANCES CLEAR

01 OPEN THE SOLID LID



ACTION

Set the trap on a dry, level surface. Lift the solid top lid from its front long-edge hinge. Confirm the central chamber is empty and the metal body is undamaged.

KEY CHECK

Solid lid open; chamber empty

02 CHECK TWO TUNNELS



ACTION

Confirm exactly two enclosed tunnel modules are fitted, one at each short-end entrance. Check that both modules are secure, clear and not bent. Do not dismantle them.

KEY CHECK

Two modules secure and clear

03 CLOSE & ENGAGE



ACTION

Lower the solid lid from the front edge and press it into its fully closed service position. Check that the lid sits flush and that neither short-end entrance is obstructed.

KEY CHECK

Solid lid flush; two entries clear

04 PLACE ALONG A WALL



ACTION

Set the closed trap flat on a dry floor with its long edge parallel and close to a confirmed wall runway. Keep the single entrance at each short end fully unobstructed.

KEY CHECK

Long edge follows the wall run



PRODUCT REFERENCE / PT-203WH

Powder-coated galvanized steel / 26 x 16 x 5 cm / 620 g / exactly two internal tunnel modules

Solid opaque lid: open the top to inspect. Keep the single entrance at each short end unobstructed.



INSPECT, RELEASE & SERVICE

STEPS 05-08

PT-203WH steel multi-catch mouse trap / solid lid / read all steps before use

LIVE-CAPTURE DEVICE - OPEN SOLID LID TO INSPECT / KEEP BOTH END ENTRANCES CLEAR

05 OPEN TO INSPECT



ACTION

Inspect at least daily and more often when conditions or local rules require. Because the lid is solid, keep the trap flat and controlled while lifting the lid to check the chamber. If occupied, close it fully before moving.

KEY CHECK

No viewing window; open to check

06 MOVE CLOSED & LEVEL



ACTION

Wear gloves. Keep the solid lid fully closed and carry the trap level with both hands supporting the base. Move it only to a release location permitted by local requirements.

KEY CHECK

Closed, level and supported below

07 RELEASE THROUGH TOP



ACTION

Set the trap flat with the open side directed away from people. Open the full top lid, withdraw both hands and allow the mouse to leave through the open chamber. Do not touch, shake or pursue it.

KEY CHECK

Open top is the release route

08 DISINFECT, WIPE & DRY



ACTION

Wear gloves. Wet contaminated surfaces with a labelled disinfectant for its stated contact time, then wipe the empty chamber with a disposable cloth. Dry fully and recheck both tunnels before reuse.

KEY CHECK

No dry sweeping; no immersion

SAFETY & SERVICE

Designed for mice. Keep out of reach of children, pets and non-target animals. Wear rubber or plastic gloves when handling a capture or contaminated trap. Do not sweep or vacuum dry rodent waste; wet it with a labelled disinfectant and observe the contact time. Follow local animal-welfare, transport and release requirements. Clean gloved hands before removing gloves, then wash hands with soap and warm water.