



OPEN, CHECK & PLACE

STEPS 01-04

PT-205 small galvanized multi-catch mice trap - solid lid / read all steps before use

LIVE-CAPTURE DEVICE - OPEN SOLID LID TO INSPECT / KEEP BOTH END ENTRANCES CLEAR

01 OPEN SOLID LID



ACTION

Wear gloves. On a dry, level surface, lift the full solid metal top on its rear long-edge hinge. Confirm the empty galvanized chamber is clean and the lid is not bent or damaged.

KEY CHECK

One opaque hinged lid; chamber empty

02 VERIFY TWO TUNNELS



ACTION

Confirm exactly two galvanized tunnel modules are fitted, one near each end. Each inward path must be clear, free of debris and correctly seated before the lid is closed.

KEY CHECK

Two tunnel modules fitted; paths clear

03 CLOSE & SECURE



ACTION

Lower the solid top without disturbing either internal module. Confirm the folded front edge and both ends sit fully down and the lid is flush around the body.

KEY CHECK

Solid lid fully closed and flush

04 PLACE ALONG A WALL



ACTION

Set the closed narrow trap flat on a dry floor with its long edge parallel and close to a wall runway. Keep the rounded entrance at each short end fully unobstructed.

KEY CHECK

Two end entries follow the wall run



PRODUCT REFERENCE / PT-205

Galvanized steel / 26.5 x 9.5 x 5 cm / 506 g* / solid lid / two internal tunnels

Open the opaque top to inspect. Close it fully before moving; keep both short-end entrances clear.



INSPECT, RELEASE & SERVICE

STEPS 05-08

PT-205 small galvanized multi-catch mice trap - solid lid / read all steps before use

LIVE-CAPTURE DEVICE - OPEN SOLID LID TO INSPECT / KEEP BOTH END ENTRANCES CLEAR

05 OPEN TO INSPECT



ACTION

Inspect on the service schedule and as local welfare rules require. Because the lid is solid, keep the trap flat and lift the top carefully to check the chamber. If occupied, close it fully before moving.

KEY CHECK

No window; open the top to check

06 MOVE THE CLOSED TRAP



ACTION

Wear gloves. Keep the lid closed and carry the trap level with both hands supporting the solid base. Move only to a release location permitted by local requirements.

KEY CHECK

Closed, level and supported below

07 RELEASE VIA OPEN TOP



ACTION

At a permitted release site, set the trap on the ground facing away from people. Open the full top, withdraw both hands and allow the mouse to leave without touching or shaking it.

KEY CHECK

Open top is the release route

08 DISINFECT, WIPE & DRY



ACTION

Wear gloves. Apply labelled disinfectant until contaminated surfaces are wet and observe its contact time. Wipe the empty chamber, dry fully and recheck both end tunnels before reuse.

KEY CHECK

No dry sweeping; both end boxes checked

SAFETY & SERVICE

Designed for mice. Keep the trap out of reach of children, pets and non-target animals. Wear rubber or plastic gloves when handling a capture or contaminated trap. Do not sweep or vacuum dry rodent waste; wet it with a labelled disinfectant and observe the contact time. Follow local animal-welfare, transport and release requirements. Clean gloved hands before removing gloves, then wash hands with soap and warm water.